



PARTS NUMBER	DESCRIPTION	QTY	EFFECTIVE DATE
1 11203-M9Q-300 N/A	RR. CUSH. UN. RUBBER BUSH	1	
1 11203-GC7-300	RR. CUSH. UN. RUBBER BUSH	1	Y
2 42311-H9A-000	RR. AXLE COLLAR	2	
3 50502-HHA-000	MAIN STAND COLLAR	1	
4 50503-HHA-000	MAIN STAND COLLAR	1	
5 5050A-HHA-000	MAIN STAND ASSY	1	
6 5052A-H9A-000	MAIN STAND SPG.ASSY.	1	
7 50542-M70-000	SPRING PLATE HOOK	1	
8 52100-HHA-010	FR. FORK	1	
9 5210A-HHA-010	FR. FORK ASSY	1	
10 90116-HHA-000	MAIN STAND PIVOT BOLT	2	
11 90754-H9A-000	DUST SEAL 26*47*7	1	
12 90755-H3C-000	DUST SEAL 26*35*7	1	
13 91051-H9A-000	BALL RADIAL BEARING	1	
14 94524-47000	CIRCLIP, IN 47	1	
15 95801-10055-07	FLANGE BOLT 10X55	2	
16 95801-08040-07	FLANGE BOLT 8*40	3	
17 50530-HHA-000	SIDE STAND COMP	1	
18 5053A-M70-000	SIDE STAND SPG. ASSY.	1	
19 90108-HHA-000	SIDE STAND PIVOT SCREW	1	
20 94030-08080	HEX NUT 8mm	1	